

# LANMFN303372

## Installation Instructions

Mud Flaps for 4920, 4930, 4940, R4045 & R4060 JD Sprayers with Narrow Fenders (N303372 or KK19039)

(1 Pair)

# LANKOTA®

270 West Park Avenue  
Huron, SD 57350  
866-526-5682

# Parts List

Part Numbers	Description	Qty
LANMF04	Sprayer Mud Flap Mount	2
LANMF05	Mud Flap Clamp Plate	2
LANMF06	Sprayer Mud Flap (21x24)	2
LANMF07	Anti-Tear Out Plate	4
<b>LANMFBH1</b>	<b>5/16" Mud Flap Bag of Hardware</b>	<b>2</b>
LANF05SP	5/16" SS Flat Washer	10
LANFH8NC	5/16" SS Top Lock Nut	6
LANF06F3	5/16" x 1" SS Hex Bolt	6
<b>LANMFBH2</b>	<b>3/8" Mud Flap Bag of Hardware</b>	<b>1</b>
LANF06FQ	3/8" x 1.5" SS Hex Bolt	4
LANF05SQ	3/8" SS Flat Washer	8
LANF21DD	3/8" SS Top Lock Nut	4



# Kit Installation



Figure 1



Figure 2



Figure 3




Figure 4

## Refer to Figures 1 - 4

1. Remove the hardware and outer plate from the back mount point of the fender.
2. Mount the mud flap mount (LANMF04) through the fender to the fender bracket with the 3/8" hardware.
3. Mount the mud flap (LANMF06) to the mount with the 5/16" hardware and clamp plate (LANMF05).



# Kit Installation



Figure 5



Figure 6

## Refer to Figures 5 & 6

4. Using a 11/32" drill bit, through the shown holes, drill holes in the fender.
5. Push a 5/16" bolt and washer through the holes.
6. Secure them in place with an anti-tear out plate (LANMF07) and a 5/16" top lock nut.
7. Tighten all hardware.
8. Repeat on other wheel.



## WARRANTY STATEMENT

Lankota Warranty only covers products produced by LANKOTA and does not cover parts made and/or sold by other aftermarket manufacturers, or the original manufacturer, or that were part of the original equipment's construction.