LANMBJDS67

Installation Instructions

Lankota Monitor Bracket for John Deere S600 & S700 Series Combines

KOTA

270 West Park Avenue **Huron, SD 57350** 866-526-5682

Parts List

Part Numbers	Description	Qty
LANMBJDS61	Combine Monitor Bracket Mount	1
LANMBJDS62	Monitor Mount Plate	1
LANMBJDS63	Bracket Spacer	3
LANFHMXCN	3/8" Nylon Wing Knob	1
LAN18A	3/8" x 1" Carriage Bolt	1
LANFB310	3/8" x 2.5" Gr 5 Hex Bolt	1
LAN18000	3/8" Flat Washer	3
LAN1618000	3/8" Nyloc Nut	1
LANFHN2KK	M6 x 35mm Flange Bolt	3



Kit Installation

Refer to Figures

- 1. Remove the three of the four screws (shown) holding the radio cover to the ceiling of the cab.
- 2. Insert an M6 x 35 bolt through the middle hole of the bracket mount (LANMBJDS61), slide a spacer (LANMBJDS63) over the bolt and then thread it into the newly exposed hole.
- 3. Repeat for other two holes and tighten all bolts.
- 4. Attach the monitor mount (LANMBJDS62) to the bracket mount with the provided hardware.
 - The 2.5" bolt, nyloc nut and (1) washer form the hinge. Leave slightly loose.
 - The carriage bolt, wing nut and (2) washers clamp the monitor mount in place.

