

LANMFN403219

Installation Instructions

Mud Flaps for R4030, R4038 & R4044 JD Sprayers with Narrow Fenders (N403219)

(1 Pair)

LANKOTA[®]

270 West Park Avenue
Huron, SD 57350
866-526-5682

Numerical Parts List

Part Numbers	Description	Qty
LANMF14	Sprayer Mud Flap Mount	2
LANMF12	Mud Flap Clamp Plate	2
LANMF13	Sprayer Mud Flap (19x24)	2
LANMF07	Anti-Tear Out Plate	4
LANMFBH1	5/16" Mud Flap Bag of Hardware	2
LANF05SP	5/16" Stainless Flat Washer	10
LANFH8NC	5/16" Stainless Top Lock Nut	6
LANF06F3	5/16" x 1" Stainless Hex Bolt	6
LANMFBH2	3/8" Mud Flap Bag of Hardware	1
LANF06FW	3/8" x 3" SS Hex Bolt	4
LANF05SQ	3/8" SS Flat Washer	8
LANF21DD	3/8" SS Top Lock Nut	4



Kit Installation



Figure 1



Figure 2



Figure 3

Figure 4



Refer to Figures 1 - 4

1. Remove the hardware and outer plate from the back mount point of the fender.
2. Mount the mud flap mount (LANMF14) through the fender to the fender bracket with the 3/8" hardware.
3. Mount the mud flap (LANMF13) to the mount with the 5/16" hardware and clamp plate (LANMF12).

Kit Installation



Figure 5



Figure 6

Refer to Figures 5 & 6

4. Using a 11/32" drill bit, through the shown holes, drill holes in the fender.
5. Push a 5/16" bolt and washer through the holes.
6. Secure them in place with an anti-tear out plate (LANMF07) and a 5/16" top lock nut.
7. Tighten all hardware.
8. Repeat on other wheel.



WARRANTY STATEMENT

Lankota Warranty only covers products produced by LANKOTA and does not cover parts made and/or sold by other aftermarket manufacturers, or the original manufacturer, or that were part of the original equipment's construction.