

LANSS600CSB

Installation Instructions

Storage Bracket & Mounting Plate Kit for John Deere® 600 Series Corn Head Storage Stands

(MY 2012 and newer)

THIS IS A SUPPLEMENTARY KIT FOR THE ABOVE CORN HEADS WITH THE FOLLOWING:

FACTORY STORAGE STAND KIT (BXE10423) AND LANKOTA STALK STOMPER KIT WITH TOOLBARS

LANKOTA®

270 West Park Avenue

Huron, SD 57350

866-526-5682

Numerical Parts List

Part Numbers	Description	Quantity
LANAXE29769SB	Storage Bracket	2
LANHXE46930	Mounting Plate	4
LAN600UBOLT	5/8" x 3.75" U-bolt	2
LAN690830	5/8" Serrated Flange Head Lock Nut	4

Pictorial Parts List



Tools Needed for Installation

- **Pair of 3/4" wrenches**
- **15/16" wrench**
- **Scraper (optional)**

Preparation

- 1. Attach desired header to the combine. Lock the header to the combine.**
- 2. Raise the header off the ground and lower the safety prop on the feeder house cylinder.**
- 3. Set the parking brake on the combine.**
- 4. Turn off the combine engine and remove the key.**

Installation

Refer to Figure 1 through 3:

IMPORTANT: Thoroughly clean and remove any dirt and debris from the bottom of header legs.

1. Using the hardware provided in the factory storage stand kit (BXE10423), pre-assemble (finger tight) a pair of Mounting Plates (LANHXE46930) with one long bolt and one lock nut toward the back.
2. Position the pre-assembly around the header leg above the bottom plate weldments and install the second long bolt and lock nut. Tighten all hardware. Ensure the Mounting Plates are still above the weldments.
3. Position the factory storage stand over the open ears of Mounting Plates and secure with the pin provided in the factory storage stand kit.



Figure 1



Figure 2



Figure 3

Refer to Figure 4 through 6:

4. Position the Storage Bracket (LANAXE29769SB) on top of toolbar tube in an un-occupied location as to avoid interference with the header cart rest pad. Install one 5/8" U-Bolt (LAN600UBOLT) and two 5/8" Serrated Lock Nuts (LAN690830). Tighten all hardware.
5. Remove the factory storage stand from bottom of header leg and position over the open ears of Storage Bracket. Secure with the pin provided in the factory storage stand kit.
6. Repeat the above step 1 through 5 for the opposite side.

For further technical assistance call Lankota at 866-526-5682



Figure 4



Figure 5



Figure 6