LANTB18207 Installation Instructions

Lankota Toolbox for John Deere STS Combines (50, 60, 70 & S-Series)

LANKOTA

270 West Park Avenue Huron, SD 57350 866-526-5682

Numerical Parts List

Part Numbers	Description	Qty
LANTB18207BX	Assembled Toolbox	1
LANTBC13	Combine Box Weldment	1
LANTBC14	Combine Lid Weldment	1
LANTBC07	Piano Hinge	1
LAN6082A22	Draw Latch	1
REDB102	1/4" x 1/2" Hex Bolt	6
LANF03JR	1/4" x 1/2" Socket Head Bolt	6
LANEJRN	1/4" Flanged Nyloc Nut	12
LANF0B1Z	#10-24 x 3/4" Machine Screw	2
LANF0DNU	#10-24 Nyloc Nut	2
LANF0F1I	3/16" Fender Washer	2
RED-TRC-TAPE	40" of 4" Wide Traction Tape	2
CAB1610SB3-343	Edge Trim	6ft
LANTBC09	Under-Frame Support	2
LAN18A00	3/8" x 1" Hex Bolt	2
LAN18A	3/8" x 1" Carriage Bolt	4
LAN18000	3/8" Flat Washer	8
REDODTT	3/8" Top Lock Nut	6

Pictorial Parts List



Kit Installation



Refer to Figures 1—4

- 1. Remove the side step from the machine. Clear the fresh edge of all dirt and debris.
- 2. Hang the box from the old step's holes with (4) 3/8" carriage bolts, washers and top lock nuts. Snug the hardware.








Figure 2

Figure 3

Kit Installation

Figure 5

Refer to Figures 5—7

- 3. Under the frame, remove the M16 nuts from the cross braces behind the toolbox and mount the supports (LANTBC09).
- 4. Set the support's notch against the cross brace plate (as shown), square it with the toolbox and tighten the nuts.
- 5. On S780 & S790 combines, the frame plates are different. Cut off the first notch to expose the second. Make smooth and repaint.
- 6. Mark the holes on the toolbox, remove it and drill them out with a 13/32" bit.
- 7. Reinstall the toolbox and connect the box and supports with 3/8" hex bolts and hardware.
- 8. Tighten all hardware.








Figure 6

Figure 7

Kit Installation



Refer to Figures

Fill it with all the tools and parts you might need.



For further technical assistance,

Call Lankota Inc. at:

1-866-526-5682

