

LANJD2CIH

Installation Instructions

Attaches any John Deere Header to Case IH Combines 2588 and older

LANKOTA®

270 West Park Avenue
Huron, SD 57350
866-526-5682

Numerical Parts List

Part Numbers	Description	Qty
LANJD2CIH	JD to CIH adapter	1

Pictorial Parts List



Kit Installation

Refer to Figure 1

1. Place header adapter plate (LANJD2CIH) over feeder house as shown.

Refer to Figures 2 & 3

2. Position lower attach pin guides so that attach pins can be snugly installed for secure attachment.
3. Tighten nuts on attach pin guides.

Figure 1



Figure 2



Figure 3



For further technical assistance,

Call Lankota Inc. at:

1-866-526-5682