

LANPSP300K & LANPSP300EK

Installation Instructions

John Deere 40 Series Poly Corn Head Snout Protectors

LANKOTA[®]

270 West Park Avenue

Huron, SD 57350

866-526-5682

Numerical Parts List

Part Numbers	Description	Qty
LANPSP300K		
LANPSP301L	Poly Snout Protector – Left Side	1
LANPSP301R	Poly Snout Protector – Right Side	1
LANPSPBH		
Bag of Hardware		
LAN030114048	3/4" Phillips Pan Head Screw	24
LAN001AB18A32	3/8" x 1-1/2" Pan Head Bolt	2
LAN3718	3/8" Serrated Lock Nut	2
LANPSP300EK		
LANPSP310L	Poly Snout Protector – Left Side	2
LANPSP310R	Poly Snout Protector – Right Side	2
LANPSPBH		
Bag of Hardware		
LAN030114048	3/4" Phillips Pan Head Screw	24
LAN001AB18A32	3/8" x 1-1/2" Pan Head Bolt	2
LAN3718	3/8" Serrated Lock Nut	2

Pictorial Parts List

			
LANPSP301L	LANPSP301R	LANPSP310L	LANPSP310R
			
LAN030114048	LAN001AB18A32	LAN3712	

Preparation

Completely remove corn hood and corn snout assembly from head and tip on one side.

Installation

Refer to Figure

1. Remove bolt that hinges on corn snout and hood assembly; see large yellow arrow.
2. Fit Stainless Steel Plate (LANPSP301L or LANPSP301R) into position as shown in Figure 1.
3. Reinstall hinge bolt and do not tighten.
4. Clamp wear plate into position and assure proper fit.
5. Once desired fit is found, attach wear plate on bottom side of snout first, using screws (LAN030114048); see small yellow arrows.
6. Install screws from back to front and finish attaching wear strip on top side of snout, see red arrows.
7. Tighten hinge bolt and repeat on opposite side.

Figure

For further technical information,
contact Lankota Inc. at:
1-866-526-5682

